

ATLANTA

H PVC
HANDRAIL

S PVC
STAIR NOSING


B PVC
BASEBOARD




ATLANTA PVC HANDRAIL

ADVANTAGES: Durable & elegant, easy to install scratch resistant

COLOR: Brown

SPECIFICATION	W	W1	W2	T	LENGTH
	55 mm	55 mm	46 mm	6 mm	30.5 M (100 ft.)




1. Measure the entire length of railing.

2. To install the PVC Handrail, heat it with a torch to soften especially the bottom portion of the handrail, then encase slowly onto the metal railing. The encasing start from the upper down to the lower staircase. About 30 cm. before the end, measure the required length and add 1-2 cm. before cutting and filling the handrail.

ATLANTA PVC STAIR NOSING

ADVANTAGES: Excellent anti-sliding function
Strong and durable

Sound absorption qualities
Easy to install & maintain

SPECIFICATION	SIZE	LENGTH	COLOR
	55 mm x 30 mm	2.2 M (7.22 ft)	Brown & Gray


1. Measure the entire length of railing.

2. To install the PVC Handrail, heat it with a torch to soften especially the bottom portion of the handrail, then encase slowly onto the metal railing. The encasing start from the upper down to the lower staircase. About 30 cm. before the end, measure the required length and add 1-2 cm. before cutting and filling the handrail.

ATLANTA PVC BASEBOARD

FLEXIBLE BASEBOARD			
	SIZE	COLOR	LENGTH
	100mm x 2mm	Brown & Gray	4M (13.12 ft)

UNIQUE BASEBOARD				
	SIZE	COLOR		LENGTH
		(Laminated)	(Non-Laminated)	
	99mm x 8.5mm	Teak Sandal Wood Oak Wood	Coffee Brown Dark Brown	3M



1. Flatten and clean the wall base before installation.
2. Measure the entire length of the wall base and cut the baseboard according to actual measurement. (Use sharp knife for Flexible baseboard and fine tooth saw for Unique baseboard).
3. Attached the inner and outer jointer on respective ends of the Unique baseboard and set it to the wall base. (See Fig 2, 3) For Flexible baseboard, apply adhesive evenly on the surface of wall base and press firmly.
4. For Flexible baseboard, set it on the wall base and press firmly. For Unique baseboard, mount on the wall then drill through baseboard and wall, use fin plug(tox) or wood dowel to fasten the screw. (See drawing for drilling / screw guide).

